


The remote adjustment of the TE30 requires the following devices:


- Calmet TE30 – the device undergoing adjustment
- Calmet C300B – three-phase voltage and current source
- Radian RD33 – three-phase reference standard

To perform the remote adjustment process, the user should:


- connect the devices




- open the RR-PCSuite software, connect with the Radian RD-3x, go to Metrics / Options, set the Update Interval to 1, press the Set button and close the RR-PCSuite software,




If the Radian RD-3x is equipped with an LCD touch screen, it is required to close all measurement windows and leave the screen on the main window



- run the TxService.exe software and select the proper version of the TE30
- connect to the devices




press the Connection button and connect to the TE30, C300B, and RD-33 in the Connection window.





After properly connecting to the devices, close the Connection window using the Close button.

- select the Cal tab by using the Cal tab button, press the Clear button and wait 60s



- press the Load procedure button and press the Start button







Calmet Sp. z o.o.
 Kukulcza 18, 65-472 Zielona Gora, Poland
 E-mail: mail@calmet.com.pl

Phone +48 68 324 04 56
 Fax +48 68 324 04 57


- select the 4.Calibration checkbox and press the Start button




- ignore the OUM – before start window and press the OK button



- set the name of result file and press the Zapisz (Save) button



- wait until the measurements are done (The message Procedure done! will appear in the lower right corner of the window)



- send the saved file (with the measurement results) along with all the required information to service@calmet.eu



Calmet Sp. z o.o.
 Kukulcza 18, 65-472 Zielona Gora, Poland
 E-mail: mail@calmet.com.pl

Phone +48 68 324 04 56
 Fax +48 68 324 04 57